



UNLOCK



Touch the recess behind the tap to release the hot side and the padlock light will go out.



DISPENSE HOT WATER



Depress the left hand lever to dispense the hot side or lift up for a continuous pour and then return to neutral to terminate the pour.



The RED LOCK will show if the safety switch is active. Once the safety sensor at the rear of the panel is touched, the lock icon light will go off for a short period (8 seconds) and the boiling water will dispense.

The GREEN LEAF icon will show if the 'Eco power-saving mode' is in operation.

The GREEN LIGHTNING BOLT icon will show if the 'Timeswitch' is in operation.

The GREEN MOON & STARS icon shows the 'Standby Mode'.

The RED & BLUE dots indicate:
Solid lights = boiling and chilled water is ready
Flashing lights = boiling and chilled water is NOT ready
Flashing yellow = fault mode